

Flowcode

Online activation - Flowcode v6

To do online activation you will first need a Matrix online account, you can register for an account here:

<http://www.matrixtsl.com/accounts/register.php>

If you have not activated Flowcode before then when you load it up for the first time a box will pop up asking you to enter your username and password, if you cannot see this box, you can get to it by going to the **Help >> Activate** menu within Flowcode.

Activate Flowcode

This copy of Flowcode is activated to: 51401178
License version: Free/Demo Version.
This is a single user license of Flowcode
You are licensed to use Flowcode for personal use only
You have 0 day(s) remaining, after which time the product will become feature-limited.

Matrix account name: Create an account

Password: Activate

? Manual activation... Close

In the box shown above to do online activation you simply must type in your **Username** and **Password** which you registered with Matrix.

After rebooting, Flowcode now should be activated.

If you have purchased a key and the licence is not correct then you may need to still attach your purchased key to your Matrix account, the FAQ here should give

Flowcode

more instructions:

<insert FAQ link>

Unique solution ID: #1064

Author: DavidA

Last update: 2015-04-01 11:12