

Flowcode

Manual offline license activation for Flowcode

This FAQ is for Flowcode 6, click to see the [Flowcode 7 Manual Activation](#).

- 1) First you will need to log in to your account via this link using your Matrix username and password: <http://www.matrixsl.com/accounts/login.php>

- 2) Secondly you will need to go the manual registration page here:


V6: http://www.matrixsl.com/accounts/v6_key_files/manual_v6_reg.php

Flowcode v6 Licence

Automatic activation via the internet is the preferred method of activating your Flowcode. If however you have no access to the internet or have strict firewall rules which prevent the automatic activation, then you will need to use the manual activation technique outlined in our [FAQ here](#).

To perform manual activation you will need three pieces of information, all present on this page:

- [Flowcode Username](#)
- [Licence File](#)
- [Activation Key](#)



Licence File

====Start key=====

[The activation key itself is heavily blurred and illegible]

====End key=====

Flowcode Username: 66319657

- 3) Download the **Licence key file** and make a note of the **Flowcode Username** and **Activation Key**.


- #### 4) Load up Flowcode

- 5) Go to Help >> Activate

- 6) Select the “Manual Activation”

Flowcode

Activate Flowcode




This copy of Flowcode is activated to: 51401178
License version: Free/Demo Version.
This is a single user license of Flowcode
You are licensed to use Flowcode for personal use only
You have 0 day(s) remaining, after which time the product will become feature-limited.

Matrix account name:

Create an account

Password:

Activate




Manual activation...

Close

7) Enter the **Flowcode Username** at the top, copy and paste the entire key (including (====Start key==== and ====End key====) into the box provided

Flowcode


Manual Activation



This copy of Flowcode is activated to: 51401178
License version: Free/Demo Version.
This is a single user license of Flowcode
You are licensed to use Flowcode for personal use only
You have 0 day(s) remaining, after which time the product will become feature-limited.


Flowcode user name:

Flowcode activation key:

====Start key====

====End key====

License file:

...



Activate

Close

8) Click the “...” button and point the dialogue box at the “**Licence Key File**” downloaded earlier.

9) Click the “Activate” button

Flowcode should restart and the new licence applied.

Unique solution ID: #1066

Author: DavidA

Flowcode

Last update: 2016-11-17 11:15