

E-blocks

Why aren't pins RB6 and RB7 working?

Hardware : EB006 MultiProgrammer Boards V1 - 6

Symptoms :

RB6 and RB7 do not work as general I/O pins

Cause :

Background debug is enabled and it uses pins RB6 and RB7

Solution :

Disable background debug in compiler options before programming the PICmicro.

Unique solution ID: #1014

Author: DavidA

Last update: 2015-03-31 12:12