

Formula Flowcode

Formula Flowcode program not running after programming

Hardware : HP629 Formula Flowcode Micromouse

Symptoms :

After the micromouse has been programmed it does not immediatley start running the program.

Cause :

There is a setting in the Formula Flowcode component properties that allows you to wait for a button press so that the micrmouse does not drive off a high surface and become damaged.

Solution :

Either press one of the buttons on the micromouse to start the program running or disable the wait function by unticking the box in the Formula Flowcode component properties.

Unique solution ID: #1022

Author: DavidA

Last update: 2015-03-31 12:21