


E BLOCKS 2

DATASHEET



Contents

About E-blocks

What Are E-blocks?	3
Connector Pinout	5
New in E-blocks 2	6

Conversion from E-blocks to E-blocks 2

BL0113 - E-blocks Upstream to E-blocks 2 Downstream	7
BL0119 - E-blocks 2 Upstream to E-blocks Downstream	8

Downstream Boards

BL0106 - Click	9
BL0114 - Combo	10
BL0117 - Proto	13
BL0127 - Actuators	14
BL0129 - Grove	16
BL0131 - GSM	19
BL0136 - WIFI	20
BL0138 - Keypad	21
BL0139 - Mono Graphical LCD	22
BL0140 - CAN Bus	23
BL0145 - Push Switch x 8	24
BL0152 - Zigbee	25
BL0154 - Micro SD Card	26
BL0155 - Expander	27
BL0156 - Splitter	28
BL0157 - Colour Graphical LCD	29
BL0158 - Upstream Connector	30
BL0161 - Manual Patch	31
BL0162 - Servo Motor	32
BL0167 - LED x 8	33
BL0169 - LCD	34
BL0170 - Bluetooth	35
BL0173 - Screw Terminals	36
BL0183 - Relay	37
BL0187 - Ethernet	38
BL0197- RFID	39


Upstream Boards

BL0011 - 8-Bit PIC Programmer - Fixed SMD IC	40
BL0032 - 16-Bit dsPIC Programmer	44
BL0036 - Raspberry Pi Shield	48
BL0055 - Arduino Uno Shield	52
BL0058 - ESP32 Programmer	56
BL0061 - ST ARM Programmer	60
BL0080 - 8-Bit PIC - DIL IC Programmer	64
BL0086 - 8-Bit AVR Programmer	68
BL0093 - FPGA Programmer	72

Additional Information

Reprogramming using mLoader	76
Reprogramming using Flowcode	76
Ghost - Auto Board ID	77
Ghost - In Circuit Debug (ICD)	78
Ghost - In Circuit Test (ICT)	79
LCD - Embedded Font Set	81


What Are E-blocks?



E-blocks2 is the latest generation of microcontroller boards from Matrix. E-blocks2 boards give you a choice of upstream programmer board. The system then allows users to connect their choice from a range of downstream boards, and build a complete system in a matter of minutes. The E-blocks2 system is ideal for everyone, from those learning in an educational environment to engineers in the industrial world. Use of E-blocks is well supported with complementary ranges of software including PIC, dsPIC, ARM and AVR Arduino IDE, Flowcode, and support for Grove® sensors. Technical support is available from our dedicated team through our forums.


Upstream E-blocks

These contain the microcontroller / microprocessor brain that is used to drive the entire system. Usually this is loaded with user firmware to drive the required embedded functionality. These boards allow the host processor to be connected to multiple downstream boards via the microcontroller / microprocessor I/O pins. Upstream boards have facilities to re-program the host processor as well as providing debugging options such as Ghost's In Circuit Debug (ICD) and In Circuit Test (ICT) functions when used with Flowcode.



Downstream E-blocks

These contain either a modularised specific feature which you want to connect to your host processor or a collection of features. For example LEDs, Switches, Displays, Communications, Sensors through to the Combo and Actuators boards. Each E-blocks 2 downstream board features an Auto ID device allowing the complete system to be analysed for potential issues and to aid in pre-configuring the software for the upstream firmware.




Designed for Education

E-blocks2 are ideal for learning about electronic systems, digital electronics and for rapid prototyping.

The boards fit together in a flat 2D layout manner allowing the entire system to be easily seen and understood.

The boards are designed for use in lab style environments and are designed to be both electrically and physically rugged whilst also being easy to use and understand. Our range consists of a number of bundles presented as individual boards or on panels (see right). These are multiple E-blocks2 boards presented in a rugged design, suitable to withstand the rigours of educational environments. We also supply a microcontroller system development kit, alongside free curriculum for those studying about microcontroller programming in school, college or university. This kit (below) is available with the upstream programmer board of the users choice.



Language Independent

E-blocks2 can be used with various programming languages allowing for flexible learning and understanding of multiple software toolchains without requiring multiple hardware sets including Flowcode, MPLAB and the Arduino IDE.

Schematics and Examples Available


E-blocks schematics are available to allow you to re-create the boards on your own PCB once you have a working system up and running. Examples written in Flowcode and C are also available from our website to speed up your getting started times.

E-blocks 2 boards are designed and manufactured in the UK



Connector Pinout

E-blocks 2 connector Layout

Upstream Connector - Female



Downstream Connector - Male





+V represents the I/O voltage of the microcontroller or processor on the upstream board. Depending on the upstream board this is either fixed at 5V or 3V3 or can be set by the user via a switch.

E-blocks 1 connector Layout

Upstream Connector—Female



Downstream Connector—Male



New in E-blocks 2

If you're already familiar with the E-blocks systems then here are some of the new features included in E-blocks 2.

Power

Automatic powering via 5V USB or DC Power Supply, no more jumpers to set
Now routed via the connector, no more flying leads

- 3.3V @ 1A
- 5V @ 500mA
- +V Microcontroller VCC Voltage
- Ground



Auto ID

Board Auto ID functionality

Available via the console window (Flowcode 7.3 Onwards)

More Auto ID support coming soon.



Modernised, Miniaturised and Ruggedized

Smaller Footprint using up to date surface mount technology

Standard boards are now 24mm wide

Mounting holes are on a 10mm spaced pitch

Over current resettable fuse protection

Varistor and R/C based EMC and EMF protection



Ghost 2 (Upstream Boards)

Microcontroller Programming

Improved high speed (HS) USB communications

In Circuit Debug (ICD) - In conjunction with Flowcode

- Program Control Start / Pause / Step Into / Step Over / Stop / Restart
- Up to 8 user defined breakpoints

In Circuit Test (ICT)- In conjunction with Flowcode

- Digital Sample rates <= 500KHz
- Analogue Sample rates <= 100KHz
- Enhanced data collection routines




Conversion - BL0113 - EB US to EB2 DS

The converter board allows old version 1 E-blocks upstream boards to be compatible with the various E-blocks 2 downstream boards. This is useful if you already have an E-blocks programmer board and want to use this with the new E-blocks 2 peripheral boards. Screw terminals are provided on the board to allow for the various power rails to be supplied to the E-blocks 2 downstream board. Only power rails that are required by the downstream board need to be connected.




BL0113 - Board Schematic




Conversion - BL0119 - EB2 US to EB DS

The converter board allows E-blocks 2 upstream boards to be compatible with the various old E-blocks downstream boards. This is useful if you already have E-blocks peripheral boards and want to use this with the new E-blocks 2 upstream boards. Screw terminals are provided on the upstream board to allow for the various power rails to be supplied to the E-blocks downstream board.




BL0119 - Board Schematic




Downstream - BL0106 - Click

The Click board provides a simple way of connecting a Click module from MikroElektronika using the Mikrobus connection and layout standard. The Click board therefore allows a wide range of different modules to be compatible with the E-blocks 2 system. Most of the Mikrobus pins are wired to allow for direct peripheral support from the E-blocks upstream controller IC. The exceptions to this are the Interrupt and Analogue pins which are exposed via turned pin sockets allowing you to wire these signals to any of the free pins of your E-blocks controller. Protection is provided on the board to ensure that 5V and 3V3 devices can work together seamlessly without causing any damage.

Port Bit	Function
0	uC RX / Click TX
1	uC TX / Click RX
2	SPI CS
3	SPI MOSI
4	SPI MISO / I2C SDA
5	SPI SCK / I2C SCL
6	PWM
7	Reset



BL0106- Board Schematic




Downstream - BL0114 - Combo

This flexible combination board is an ideal platform for learning and project development. The board will work with any upstream E-blocks system allowing multiple technologies to be explored using a single downstream E-blocks board. The board is ideal for using in conjunction with our CD ROM resources to help learn programming using flow charts, C or assembly code. The graphical LCD is driven via an intelligent conversion module to allow it to be treated as a standard Alphanumeric HD44780 compatible device.

Features

- 16 Individual LEDs
- 16 Individual Switches
- Quad 7-Segment Display
- 20 x 4 Character Alphanumeric LCD
- On-board sensors (Light / Potentiometer)
- Audio Output Socket

Refer to the [LCD Key Differences](#) section for more info on the LCD including the in-built LCD character set.




The ANA/DIG switch specifies the connections for pins 0 and 1 on Port 1. In the DIG position the pins will be connected to the digital circuitry including the Switch, LED and 7-Seg Common Pin. In the ANA position the pins will be connected to the light sensor and potentiometer inputs respectively. Connecting an Audio jack to the audio socket disconnects pin 2 and 3 on Port 1 from the digital circuitry (Switch, LED and 7-Seg Common Pin).

Connections

	PORT1								Port2							
	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
7 Seg					Com3	Com2	Com1	Com0	DP	G	F	E	D	C	B	A
LCD											Enable	RS	Data3	Data2	Data1	Data0
Analog							Pot	Light								
Sound					Out R	Out L										

Downstream - BL0114 - Combo


Board Layout




- | | | | |
|----|--------------------------|-----|-------------------------|
| 1. | Port 1 EB2 Connector | 7. | Audio Output Socket |
| 2. | Port 2 EB2 Connector | 8. | LCD On/Off Switch |
| 3. | Port 1 Switches and LEDs | 9. | 7-Segment On/Off Switch |
| 4. | Port 2 Switches and LEDs | 10. | Analogue/Digital Switch |
| 5. | 7-Segment Display Bank | 11. | Analogue Potentiometer |
| 6. | Alphanumeric LCD | 12. | Analogue Light Sensor |

Downstream - BL0114 - Combo


Block Diagram



7 Segment Display—Segment Map




Board Schematic




Downstream - BL0117 - Prototype

The Proto board allows for easy addition of custom circuitry into the E-blocks 2 system. The board provides an array of standard 2.54mm pitch holes which can be used to permanently solder electronics onto the E-blocks board. The board is also supplied with a small breadboard allowing for temporary electronics to be created and tested with the E-blocks 2 system. The small breadboard features a sticky back so it can be attached to the top of the Proto E-block circuit board if required. The board exposes the eight data lines from the microcontroller port as well as the various power connections +V, 3V3, 5V and GND via turned pin sockets suitable for linking to your circuitry using single core wire.



The small breadboard is supplied with the Prototype board and can be fixed to the top of the prototype board if required by using the provided sticky pad on the back of the breadboard. Components can also be soldered directly to the Prototype board as required. The prototype board comes complete with six Dupont style male to male cables allowing you to easily connect the signals from your upstream board to your custom circuitry.

BL0117 - Board Schematic




TITLE:		DATE:
BL0117		28/11/17
E-blocks 2 - Prototype Board		PAGE:
BY: Ben Rowland		1/1
REV: 1		


Downstream - BL0127 - Actuators

The Actuators board allows for investigation into several different motor types. Included on the board is a DC motor with both analogue and digital feedback, a servo motor and a stepper motor plus the circuitry to drive the motors. The DC motor is driven using a standard H-Bridge driver IC and can be driven using simple digital on/off right through to analogue pulse width modulation (PWM) techniques. By monitoring the feedback signal, a closed loop control system can be made to control the speed of the DC motor. A second H-Bridge driver IC is used to drive the four coils of the stepper motor allowing for full step and half step operation. The Stepper motor features an internal gearbox to provide a high level of torque and precise angle control. The servo motor is a standard R/C servo motor with a supplied actuator arm. The board features a DC socket to allow the various motors to be powered from a secondary 5 - 6V power supply.

Port Bit	Function
0	Servo Motor
1	DC Motor A
2	DC Motor B
3	Stepper A
4	Stepper B
5	Stepper C
6	Stepper D
7	DC Feedback




BL0127 - Board Schematic



Downstream - BL0127 - Actuators

Board Layout



- | | |
|----------------------------|--|
| 1. Port EB2 Connector | 8. DC Motor Feedback Analogue/Digital Switch |
| 2. Servo Motor | 9. Actuators On/Off Switch |
| 3. Stepper Motor | 10. Power LED |
| 4. DC Motor | 11. Power screw terminals |
| 5. DC Motor Driver IC | 12. Power DC Socket Inner Positive 5V-6V |
| 6. Stepper Motor Driver IC | 13. DC Motor Analogue Speed Measurement IC |


The stepper motor has a 64 step revolution count and features an internal 64:1 gearbox which equates to 4096 steps per revolution. For the stepper to work with the Flowcode Stepper motor component the pin connection properties must be setup as follows, replacing PORTB with the correct EB2 port.

Connections	
Coil 1	\$PORTB.3
Coil 2	\$PORTB.5
Coil 3	\$PORTB.4
Coil 4	\$PORTB.6


Downstream - BL0129 - Grove

The Grove board allows for the easy addition of a large number of peripherals and sensors from the Seeed Studio range of Grove modules. The board can be used with up to four Grove modules at a time. Care should be taken to ensure that the system voltage is compatible with all the connected Grove modules to avoid damaging the Grove module.

Port Bit	Function
0	Socket 1 Even
1	Socket 1 Odd
2	Socket 2 Even
3	Socket 2 Odd
4	Socket 3 Even
5	Socket 3 Odd
6	Socket 4 Even
7	Socket 4 Odd



BL0129 - Board Schematic



TITLE: BL0129 E-blocks 2 - Grove Board	DATE: 13/09/17
BY: Ben Rowland	PAGE: 1/1
REV: 1	

Downstream - BL0129 - Grove Sensors



BL0615 - Ultrasonic Ranger

Connection: Single digital i/o pin (on the even pin) **Voltage:** 5V

Usage: Trigger with a pulse (at least 10us) on the signal pin, and read the length of the pulse received on the same pin.

Flowcode component: Hardware -> E-blocks 2 Sensors -> Ultrasonic Ranger

Warning: Do not hot plug the Grove-Ultrasonic-Ranger, otherwise it will damage the sensor



BL0644 - Temperature Sensor

Connection: Single analogue output pin (on the even pin) **Voltage:** 5V / 3V3

Usage: Read the output signal as an analogue voltage and convert into a temperature.

Flowcode component: Hardware -> E-blocks 2 Sensors -> Temperature Sensor



BL0661 - Infrared Reflective Sensor

Connection: Single digital output pin (on the even pin) **Voltage:** 5V / 3V3

Usage: Read the output signal as a digital voltage active low. The detection threshold is set using the onboard potentiometer.

Flowcode component: Hardware -> E-blocks 2 Sensors -> Infrared Reflective Sensor




BL0668 - Temperature & Humidity Sensor (SHT31)

Connection: I²C Interface (SDA on the odd pin, SCL on the even pin) **Voltage:** 5V / 3V3

Usage: Read the sensor signals by performing a digital I²C communications protocol.

Flowcode component: Hardware -> E-blocks 2 Sensors -> Temp / Humidity (Grove 101020212)




BL0665 - Water Sensor

Connection: Single analogue output pin (on the even pin) **Voltage:** 5V

Usage: Read the output signal as an analogue voltage.

Flowcode component: Hardware -> E-blocks 2 Sensors -> Water Sensor

Downstream - BL0129 - Grove Sensors




BL0679 - Sound Sensor

Connection: Single analogue output pin (on the even pin) **Voltage:** 5V

Usage: Read the output signal as an analogue voltage.

Flowcode component: Hardware -> E-blocks 2 Sensors -> Sound Sensor



BL0691 - 6-Axis Accelerometer & Gyroscope

Connection: I²C Interface (SDA on the odd pin, SCL on the even pin) **Voltage:** 5V / 3V3

Usage: Read the sensor signals by performing a digital I²C communications protocol.

Flowcode component: Hardware -> E-blocks 2 Sensors -> 6-Axis Accel & Gyro LSM6DS3




BL0663 - PIR Motion Sensor

Connection: Single digital output pin (on the even pin) **Voltage:** 5V / 3V3

Usage: Read the output signal as an digital voltage active high.

Flowcode component: Hardware -> E-blocks 2 Sensors -> PIR Motion BISS0001




BL0659 - I2C Color Sensor V2

Connection: I²C Interface (SDA on the odd pin, SCL on the even pin) **Voltage:** 5V / 3V3

Usage: Read the sensor signals by performing a digital I²C communications protocol.

Flowcode component: Hardware -> E-blocks 2 Sensors -> I2C Color Sensor



BL0640 - Barometer Sensor (BMP280)

Connection: I²C Interface (SDA on the odd pin, SCL on the even pin) **Voltage:** 5V / 3V3


Usage: Read the sensor signals by performing a digital I²C communications protocol.

Flowcode component: Hardware -> E-blocks 2 Sensors -> Barometer BMP280

Downstream - BL0131 - GSM

The GSM board allows the E-blocks system to connect and communicate with a mobile phone (GSM) network. It can be used to make and receive phone calls, send and receive text messages as well as go onto the internet using GPRS for IoT style applications. The board features audio sockets to allow the board to be connected to a standard headset and microphone. A micro SIM socket is hidden away under the GSM module and a quad band antenna is included.

Port Bit	Function
0	uC RX / GSM TX
1	uC TX / GSM RX
2	Reset
3	Ring
4	
5	
6	
7	




GSM Chip : SIMCOM SIM800

Transmitting Frequency: 824 ~ 849 MHz

Receiving Frequency : 869 ~ 894 MHz

Transmitting power: 2W

BL0131 - Board Schematic




TITLE: BL0131 E-blocks 2 - GSM Board	DATE: 12/02/19
BY: Ben Rowland	PAGE: 1/1
REV: 1	

Downstream - BL0136 - WIFI

The WIFI board allows the E-blocks system to connect and communicate with an existing WIFI network. It can also be used to create a data access point that other WIFI enabled devices can connect to. WIFI is provided via the popular ESP12F module which is fully certified and ruggedized. The on-board TCP/IP stack allows for easy communications without the need for a software TCP/IP stack running on the E-blocks upstream board. Applications include serving HTML webpages, cloud based statistic logging and internet of things (IOT).

Port Bit	Function
0	uC RX / WIFI TX
1	uC TX / WIFI RX
2	Reset
3	
4	
5	
6	
7	



WIFI Chip : ELECROW ESP-12S


Frequency Range : 2412-2484 MHz

Power : Continuous transmission=> Avg: 71mA, Peak: 300mA

Modem Sleep : 20mA , Light Sleep :-2mA,

Deep Sleep : -0.02mA



BL0136 - Board Schematic




Downstream - BL0138 - Keypad 3x4

The Keypad board allows for simple data entry using an array of switch inputs which can be added to the E-blocks 2 system. Keypads are useful tools as they allow you to enter numeric and textual data into the embedded system. The switches are all push to make type and read by controlling the logic level of the columns and reading back the state of the rows. Only a single active switch on the keypad can be read at once.

Port Bit	Function
0	Column 1
1	Column 2
2	Column 3
3	
4	Row A
5	Row B
6	Row C
7	Row D



BL0138 - Board Schematic




 MATRIX TSL www.matrixtsl.com (c) Copyright 2017 Matrix TSL	
TITLE:	DATE:
BL0138	20/06/18
E-Blocks 2 Keypad Board	PAGE
	1/1
BY: Ben Rowland	REV: 1.0


Downstream - BL0139 - Mono Graphical LCD

The Mono Graphical LCD board provides a 32 x 128 pixel monochrome graphical display capable of drawing text, displaying images and symbols. The board could also be made to create some simple games or animations. The board features a ST7567 display driver IC and the display can be driven and fully simulated within the Flowcode software.

Port Bit	Function
0	
1	
2	
3	CS
4	Reset
5	A0
6	SDA
7	SCL



BL0139 - Board Schematic




		MATRIX TSL www.matrixtsl.com (c) Copyright 2017 Matrix TSL	
TITLE:		DATE:	
BL0139 E-blocks 2 - Mono GLCD Board		07/12/17	
BY: BRowland		PAGE:	
REV: 1		1/1	


Downstream - BL0140 - CAN Bus

The CAN bus board allows the E-block system controller to connect with other controllers. CAN is widely used in automotive applications due to its low cost, high data throughput and noise immunity. The board can be used with upstream E-blocks boards both with or without CAN bus peripherals allowing the maximum flexibility. The board includes both a CAN transceiver and a CAN controller which can be accessed via a simple SPI bus. For development and training purposes the board is fitted with three switches and two LEDs which can be controlled using the CAN transceiver chip. Flowcode macros for this E-block are available.

Port Bit	Internal (INT)	External (EXT)
0		INT
1		
2	TXD	CS
3	RXD	MOSI
4		MISO
5		SCK
6		
7		




BL0140 - Board Schematic




TITLE:	DATE:
BL0140	13/12/17
E-blocks 2 - CAN Bus Board	PAGE:
BY: Ben Rowland	REV: 1
	1/1

Downstream - BL0145 - Switch x 8

The Switch board allows a bank of eight switch inputs to be added to the E-blocks 2 system. Switches are useful tools as they allow you to control what is happening in the system. The switches are all push to make type and active high meaning the voltage to the microcontroller port pins is low when the switch is not pressed and high when the switch is pressed.



Each switch is in the active high configuration. When the switch is pressed R1 pulls the signal to the E-block port pin high. When the switch is not pressed R2 pulls the signal to the E-block port pin low to avoid picking up electrical noise from the environment (floating).




TITLE: BL0145 E-blocks 2 - Push Switch Board		DATE: 15/08/17
BY: Ben Rowland	REV: 1	PAGE: 1/1

Downstream - BL0152C & BL0152R - Zigbee


The Zigbee board uses a Series 2 XBEE module to allow you to connect one of more E-blocks systems together using the Zigbee (wireless area network) standard or to connect your system to a third party Zigbee system. The modules used are compliant with the 2007 Zigbee Pro standard. Because of the nature of the Zigbee standard there are two different boards the BL0152R is pre-programmed to behave as a router node in a Zigbee system. The BL0152C is pre-programmed to behave as a co-ordinator node in a Zigbee system.

Port Bit	Function
0	uC RX / XBEE TX
1	uC TX / XBEE RX
2	Sleep
3	RTS
4	CTS
5	
6	
7	



Zigbee Chip : DiGi DiGi XBee S2C
 Frequency Band : 'ISM 2.4 GHz
 Power: 3.1mW (+ SdBm) ""63mW (+ 18dBm)

BL0152 - Board Schematic




TITLE:	BL0152	DATE:	18/10/17
	E-blocks 2 - XBEE Board	PAGE:	1/1
BY:	Ben Rowland	REV:	1


Downstream - BL0154 - Micro SD Card

The micro SD card board allows a large amount of data storage to be added to the E-blocks system. The board provides a means of reading and writing data to the SD card as well as providing level shifting to allow 5V and 3V3 systems to be compatible. The board also provides a means of detecting if the card is present via a switch built into the card socket. The micro SD card is inserted by pushing it into the socket with the SD contacts pointing down. The SD card is removed from the socket by first pushing it inwards to unlock it from the socket before pulling it back out.

Port Bit	SPI Mode
0	
1	
2	CS
3	MOSI
4	MISO
5	CLK
6	SW
7	




BL0154 - Board Schematic




Downstream - BL0155 - Expander

The expander board allows multiple E-blocks 2 boards to be connected to a single upstream E-blocks 2 port. The data pins are controlled using an MCP23S17 I/O expander IC via an SPI connection to the host controller. The I/O expander provides digital input and output functionality as well as more advanced features such as interrupt on change. The board also features three DIP switches which are used to set the address of the I/O expander allowing for up to 8 expander boards to exist on the same SPI connections. The board also features three DIP switches which are used to set the address of the I/O expander allowing for up to 8 expander boards to exist on the same SPI connections. The auto ID functionality is forwarded onto the connected boards. Please note that only one board should be connected to ports labelled 1 and ports labelled 2 to allow the expansion pins to be unique and auto ID to function correctly.

Port Bit	Function
0	
1	Reset
2	CS
3	SCK
4	MISO
5	MOSI
6	
7	




BL0155 - Board Schematic




TITLE:	DATE:
BL0155	15/11/17
E-blocks 2 - I/O Expander	PAGE:
BY: BenRowland	1/1
REV: 1	

Downstream - BL0156 - Splitter

The splitter board allows multiple E-block 2 boards to be connected to a single upstream E-blocks 2 port. The data pins are shared between the connected boards and the auto ID functionality is forwarded onto the connected boards. Please note that only one board should be connected to ports 1 and 2 to allow the auto ID to function correctly.



BL0156 - Board Schematic




Downstream - BL0157 - Colour GLCD Board

The Colour Graphical LCD board provides a 160 x 128 pixel TFT colour graphical display capable of drawing text, displaying images and symbols in 16-bit colour. The board could also be used to create some simple game or animation graphics. Featuring a Flowcode compatible ILI9163C display driver IC the display can be programmed and fully simulated within the Flowcode environment. The board also features a dimmable backlight to provide maximum display visibility even in the dark. The backlight will default to on when the backlight pin is left floating or driven high. The backlight brightness can be controlled by using PWM techniques on the backlight control pin.

Port Bit	Function
0	Data
1	Clock
2	CS
3	A0
4	Reset
5	Backlight
6	
7	




BL0157 - Board Schematic




TITLE:	BL0157	DATE:	30/08/18
	E-blocks 2 - Graphical LCD Board	PAGE:	1/1
BY:	Ben Rowland	REV:	1

Downstream - BL0158 - Upstream Connector

The upstream connector board allows one upstream E-block board to be connected directly to another to allow for things like chip to chip communications to be explored and implemented. Chip to chip communications might include busses such as I2C, SPI or UART peripherals. The Upstream connector board features an IDC compatible header allowing for ribbon cables to be used to connect the boards together using simple push fit connections. The board also features a patch section allowing data pins to be re-wired through to other data pins. For example when connecting a UART to a UART the TX pin from one upstream board connects to the RX pin of the other upstream board and visa versa.




BL0158 - Board Schematic




TITLE:		DATE:
BL0158		05/01/18
E-blocks 2 - Upstream Link		PAGE:
		1/1
BY: Ben Rowland	REV: 1	

Downstream - BL0161 - Manual Patch

The patch board allows the various data signals to be re-ordered between upstream and downstream boards. This is useful for upstream processors with peripherals using none standard connections or for combining signals together from multiple ports. The patch board comes complete with six Dupont style male to male cables allowing you to easily assign the signals to your downstream board.




BL0161 - Board Schematic




Downstream - BL0162 - Servo Motor

The servo motor board allows up to eight servo motors to be connected to an E-blocks 2 system. Up to eight channels can be individually controlled for connection to device such as servo motors or brushless electronic speed controllers. The board also provides a DC socket allowing the motors to be powered from an external DC power supply separate from the E-blocks 2 supply rails. Overvoltage protection is built onto the board stopping any voltages greater than 6V from being allowed to damage the connected motors.





BL0162 - Board Schematic




Downstream - BL0167 - LED x 8

The LED board allows a bank of eight LED indicators to be added to the E-blocks 2 system. LEDs are useful tools as they allow you to indicate what is happening or the ongoing real time status of the system. LEDs can be driven in a digital way using on or off output states or an analogue way using pulse width modulation (PWM) techniques.



Each LED is in the active high configuration. When the E-blocks port pin outputs a logic high the LED will light. When the port pin outputs a logic low or is in input mode the LED will be off. Each LEDs brightness level can be altered by switching the LED on and off at high speed (PWM).

BL0167 - Board Schematic



TITLE:	DATE:
BL0167	22/09/17
E-blocks 2 - LED Board	PAGE:
BY: Ben Rowland	1/1
REV: 1	

Downstream - BL0169 - LCD


The LCD board provides a 20 x 4 character alphanumeric display compatible with the standard HD44780 type displays. An onboard microcontroller listens for HD44780 compatible commands and converts the incoming commands into SPI packets that drive the modern chip on glass (COG) graphical display.

Refer to the [LCD Key Differences](#) section for more info on the LCD including the in-built LCD character set.

Port Bit	LCD Pin
0	Data 0
1	Data 1
2	Data 2
3	Data 3
4	RS
5	Enable



BL0169 - Board Schematic




<p>MATRIX TSL www.matrixtsl.com (c) Copyright 2017 Matrix TSL</p>	
TITLE: BL0169 E-blocks 2 - LCD Board	DATE: 22/09/17
BY: BRowland	PAGE: 1/1
REV: 1	

Downstream - BL0170 - Bluetooth


The Bluetooth board contains a Microchip RN4678 module which adds fully certified Bluetooth 4.0 functionality to your E-blocks system. The Bluetooth modules has a transmit power of +2dBm, which should give a 100 yard transmission range at a data transfer rate of 50Kbps. The modules is programmed using an asynchronous serial AT command style protocol which can be interfaced to any upstream controller with a UART facility. The module allows for exploration of both Bluetooth classic (BR/EDR) and Low Energy (LE) protocols. Flowcode macros to support the use of this board are available.

Port Bit	Function
0	uC RX / BT TX
1	uC TX / BT RX
2	
3	
4	
5	
6	
7	



Bluetooth Chip : Microchip RN4678
 Frequency Range : 2.402 " 2.480 GHz
 Power Range : - 92dBm " 2 dBm


BL0170 - Board Schematic




TITLE:	BL0170	DATE:	23/10/17
	E-blocks 2 - BLUETOOTH	PAGE:	1/1
BY:	Ben Rowland	REV:	1

Downstream - BL0173 - Screw Terminals

The terminals board provides screw terminals which can be used to directly connect wires to an E-blocks 2 system. Terminals are buffered by 220ohm resistors to provide protection for upstream boards. The various E-blocks 2 supply voltage rails are also available as screw terminals allowing you to power your external electronic devices.




BL0173 - Board Schematic




TITLE:	DATE:
BL0173	28/11/17
E-blocks 2 - Terminal Board	PAGE:
	1/1
BY: Ben Rowland	REV: 1

Downstream - BL0183 - Relay

The relay board provides two electrically controllable relays which act as isolated switches. The external connections to the relays are provided using screw terminals and both the normally open (NO) and normally closed (NC) connections are available allowing for the maximum flexibility. Each relay features an LED to indicate when the relay is active. Two relay boards can be used on the same E-blocks port by using a BL0156 Splitter board and setting the slide switch on each board to opposing positions. The relays are rated for use with Mains voltage but great care should be taken to avoid electrical shocks when using high voltage such as mains. We recommend to always use an inline RCD and to place the E-blocks boards into a rugged, insulated enclosure with clear danger warnings.




BL0183 - Board Schematic




Downstream - BL0187 - Ethernet

The Ethernet board provides a means of communicating via a standard RJ45 network cable with a router or network. It can be used for local network communications as well as internet based communications and IoT style applications. The board features a switch to allow two boards to be used together on the same E-blocks port using a splitter board for firewall type applications.

Port Bit	Function
0	CS0
1	CS1
2	Reset
3	MOSI
4	MISO
5	SCK
6	INT
7	



BL0187 - Board Schematic



TITLE: BL0187 E-blocks 2 -Ethernet Board	DATE: 03/09/18
BY: Ben Rowland	PAGE: 1/1
REV: 1	

Downstream - BL0197 - RFID


The RFID board provides a means of communicating with standard RFID type tags. The board supports MIFARE and ICODE type tags and features an on-board antenna complete with tuning capacitor. The board features a buzzer which can be programmed to beep on the presence of a RFID tag as well as signals back to the microcontroller to detect when a valid tag is present.

Port Bit	Function
0	uC RX / RFID TX
1	uC TX / RFID RX
2	Beep
3	LED
4	CTS
5	
6	
7	




RFID Chip : ib Technology MicoRWD mifare
 Frequency: 13.56 MHz Power : 150 μ A

BL0197 - Board Schematic




Upstream - BL0011 - 8-Bit PIC Programmer

The 8-bit PIC microcontroller programmer connects to your PC via USB to provide you with a powerful microcontroller programming and debugging platform. The board can be used with various programming languages including: Assembly, C and Flowcode. To program the PIC on the board a free tool called mLoader is available to download from the Matrix TSL website. The board comes complete with a powerful PIC16F18877 microcontroller. The board presents all port pins collected together as E-blocks 2 sockets. The board takes power from an external power supply or from the micro USB port. Using the board with Flowcode allows the use of the advanced Ghost debugging features including in circuit debugging, real time pin monitoring and bus decoding. Microchip PICkit compatible sockets are fitted to provide an alternative reprogramming and debugging techniques.




BL0011 - Block Diagram




Upstream - BL0011 - 8-Bit PIC Programmer

Board Layout


1. DC Power Jack 7.5 - 12V
2. Micro USB Socket
3. Status LEDs
4. Power Output Terminals
5. Ghost Microcontroller IC
6. High Speed USB Transceiver
7. Target Microcontroller 16F18877
8. Voltage Selection Switch
9. Oscillator Selection Switch
10. 8MHz Socketed Crystal
11. Reset Switch
12. EB2 Port A Connector
13. EB2 Port B Connector
14. EB2 Port C Connector
15. EB2 Port D Connector
16. EB2 Port E Connector



BL0011 - Board Schematic



Upstream - BL0011 - 8-Bit PIC Programmer



Upstream - BL0011 - 8-Bit PIC Programmer

Ghost Specification

VCC Voltage: 5V / 3V3
 ICD Pins: Clock = B6 / Data = B7
 ICT Digital Channels: 35
 ICT Analogue Channels: 17
 ICT Port Pins Map:

	7	6	5	4	3	2	1	0
Port A	A7 **	A6 **	A5	A4	A3	A2	A1	A0
Port B	B7	B6	B5	B4	B3	B2	B1	B0
Port C	C7	C6	C5	C4	C3	C2	C1	C0
Port D	D7	D6	D5	D4	D3	D2	D1	D0
Port E					E3	E2	E1	E0


White = No Sampling / Red = Digital Only / Blue = Analogue Only / Green = Digital & Analogue

** Port pins A6 and A7 are only available when the microcontroller is configured for an internal oscillator and the XTAL / A6&7 switch on the board is in the A6&7 position.


Upstream - BL0032 - 16-Bit dsPIC Programmer

The 16-bit dsPIC microcontroller programmer connects to your PC via USB to provide you with a powerful microcontroller programming and debugging platform. The board can be used with various programming languages including: Assembly, C and Flowcode. To program the dsPIC on the board a free tool called mLoader is available to download from the Matrix TSL website. The board comes complete with a powerful dsPIC33EP256MU806 microcontroller. The board presents all port pins collected together as E-blocks 2 sockets. The board takes power from an external power supply or from the micro USB port. Using the board with Flowcode allows the use of the advanced Ghost debugging features including in circuit debugging, real time pin monitoring and bus decoding. Microchip PICkit compatible sockets are fitted to provide an alternative reprogramming and debugging techniques.

Port Bit	PORT F/C	PORT D/G
0	F0	D8
1	F1	D9
2	N/C	D10
3	F3	D11
4	F4	G6
5	F5	G7
6	C13	G8
7	C14	G9




BL0032 - Block Diagram




Upstream - BL0032 - 16-Bit dsPIC Programmer

Board Layout


1. DC Power Jack 7.5 - 12V
2. Micro USB Socket
3. Status LEDs
4. Power Output Terminals
5. Ghost Microcontroller IC
6. High Speed USB Transceiver
7. Target Microcontroller (33EP256MU806)
8. 8MHz Socketed Crystal
9. Target Micro USB Socket
10. Reset Switch
11. EB2 Port B 0-7 Connector
12. EB2 Port B 8-15 Connector
13. EB2 Port D 0-7 Connector
14. EB2 Port E 0-7 Connector
15. EB2 Port F/C Connector
16. EB2 Port D/G Connector



BL0032 - Board Schematic



Upstream - BL0032 - 16-Bit dsPIC Programmer



Upstream - BL0032 - 16-Bit dsPIC Programmer

Ghost Specification


VCC Voltage: 3V3
 ICD Pins: Clock = B6 / Data = B7
 ICT Digital Channels: 47
 ICT Analogue Channels: 17
 ICT Port Pins Map:

	7	6	5	4	3	2	1	0
Port BL	B7	B6	B5	B4	B3	B2	B1	B0
Port BH	B15	B14	B13	B12	B11	B10	B9	B8
Port D	D7	D6	D5	D4	D3	D2	D1	D0
Port E	E7	E6	E5	E4	E3	E2	E1	E0
Port F/C	C14	C13	F5	F4	F3		F1	F0
Port D/G	G9	G8	G7	G6	D11	D10	D9	D8


White = No Sampling / Red = Digital Only / Blue = Analogue Only / Green = Digital & Analogue

Upstream - BL0036 - Raspberry Pi Shield

The Raspberry Pi Shield allows you to connect a Raspberry Pi PCB computer (such as the Raspberry Pi 3 Model B) up to an E-blocks system to provide you with a powerful programming and debugging platform. The board presents all GPIO and peripheral pins collected together as E-blocks 2 sockets. The board takes power from an external power supply or from the micro USB port or from the Pi's power source. Using the board with Flowcode allows the use of the advanced Ghost debugging features including in circuit debugging, real time pin monitoring and bus decoding.




BL0036 - Block Diagram



Upstream - BL0036 - Raspberry Pi Shield

Board Layout

1. DC Power Jack 7.5 - 12V
2. Micro USB Socket
3. Status LEDs
4. Power Output Terminals
5. Ghost Microcontroller IC
6. High Speed USB Transceiver
7. Raspberry Pi GPIO Socket
8. EB2 Port A
9. EB2 Port B
10. EB2 Port C
11. EB2 Port D



GPIO Pin Mapping (RPI 2 & 3)

Pin	7	6	5	4	3	2	1	0
PortA			GPIO 0	GPIO 1	GPIO 5	GPIO 6	GPIO 7	GPIO 4
PortB	GPIO 16	GPIO 26	GPIO 25	GPIO 24	GPIO 23	GPIO 22	GPIO 17	GPIO 27
PortC	GPIO 2	GPIO 3	GPIO 11	GPIO 9	GPIO 10	GPIO 8	GPIO 14	GPIO 15
PortD			GPIO 21	GPIO 19	GPIO 20	GPIO 18	GPIO 12	GPIO 13

Peripheral Pin Mapping (RPI 2 & 3)

Pin	7	6	5	4	3	2	1	0
PortA								
PortB								
PortC	SDA1	SCL1	SCK0	MISO0	MOSIO	SPIOSS0	TX	RX
PortD			SCK1	MISO1	MOSI1	SPI1SS0	PWM0	PWM1

Upstream - BL0036 - Raspberry Pi Shield

Ghost Specification


VCC Voltage: 3V3
 ICD Pins: Clock = B6 / Data = B7
 ICT Digital Channels: 28
 ICT Analogue Channels: 0
 ICT Port Pins Map:

	7	6	5	4	3	2	1	0
Port A			A5	A4	A3	A2	A1	A0
Port B	B7	B6	B5	B4	B3	B2	B1	B0
Port C	C7	C6	C5	C4	C3	C2	C1	C0
Port D			D5	D4	D3	D2	D1	D0


White = No Sampling / Red = Digital Only / Blue = Analogue Only / Green = Digital & Analogue

Upstream - BL0055 - Arduino Uno Shield

The Arduino Uno Shield connects to your PC via USB to provide you with a powerful microcontroller programming and debugging platform. The board can be used with various programming languages including: Assembly, C, Arduino IDE and Flowcode. To program the Arduino on the board a free tool called mLoader is available to download from the Matrix TSL website. The board presents all port pins collected together as E-blocks 2 sockets. The board takes power from an external power supply or from the micro USB port. Using the board with Flowcode allows the use of the advanced Ghost debugging features including in circuit debugging, real time pin monitoring and bus decoding. Microchip AVR-ISP compatible sockets are fitted to provide an alternative reprogramming and debugging techniques.




BL0055– Block Diagram




Upstream - BL0055 - Arduino Uno Shield

BL0055 - Board Layout

1. DC Power Jack 7.5 - 12V
2. Micro USB Socket
3. Status LEDs
4. Power Output Terminals
5. Ghost Microcontroller IC
6. High Speed USB Transceiver
7. Arduino Connection Headers
8. ISP Header
9. Reset Switch
10. EB2 Port C Connector
11. EB2 Port D Connector
12. EB2 Port B Connector



BL0055 – Flowcode Compatibility




When selecting a target device in Flowcode choose the device that matches your Arduino board.

For example:


AVR -> Arduino -> Arduino Uno R3 PDIP

In the General Options tab select the correct COM port for the Arduino device. If no COM port is available then check your Arduino device is connected to the USB and that the USB driver is correctly installed.

Please note the Arduino needs to be connected to the USB to allow it to be re-programmed. The E-block needs to be connected to the USB to allow Ghost (ICD/ICT) features.



Upstream - BL0055 - Arduino Uno Shield



Upstream - BL0055 - Arduino Uno Shield

Ghost Specification

VCC Voltage: 5V / 3V3 – Based on Arduino (Usually 5V)

ICD Pins: Clock = D1 / Data = D0

ICT Digital Channels: 20

ICT Analogue Channels: 6

ICT Port Pins Map:


	7	6	5	4	3	2	1	0
Port A			A5 (C5) *	A4 (C4) *	A3 (C3)	A2 (C2)	A1 (C1)	A0 (C0)
Port D0-7	D7 (D7)	D6 (D6)	D5 (D5)	D4 (D4)	D3 (D3)	D2 (D2)	D1 (D1)	D0 (D0)
Port D8-13	A5 (C5) *	A4 (C4) *	D13 (B5)	D12 (B4)	D11 (B3)	D10 (B2)	D9 (B1)	D8 (B0)

White = No Sampling / Red = Digital Only / Blue = Analogue Only / Green = Digital & Analogue


* Port pins A4 and A5 are shared between Port A0-A5 and Port D8-D13 to allow for a second full E-blocks port. This is useful for enabling downstream boards such as the Actuators board to be used alongside a Combo board.

Upstream - BL0058 - ESP32 Programmer

The ESP32 Programmer board connects to your PC via USB to provide you with a powerful microcontroller programming and debugging platform. The board features a powerful dual core 32-bit microcontroller running at 240MHz and features built in Bluetooth and WIFI communications. The board can be used with various programming languages including: Assembly, C, Arduino IDE and Flowcode. To program the ESP32 on the board a free serial tool is available to download as part of the Arduino or Flowcode toolchains. The board presents all port pins collected together as E-blocks 2 sockets. The board takes power from an external power supply or from the micro USB port. Using the board with Flowcode allows the use of the advanced Ghost debugging features including in circuit debugging, real time pin monitoring and bus decoding.




BL0055- Block Diagram



Upstream - BL0058 - ESP32 Programmer

BL0058 - Board Layout

1. DC Power Jack 7.5 - 12V
2. Micro USB Socket
3. Status LEDs
4. Power Output Terminals
5. Ghost Microcontroller IC
6. High Speed USB Transceiver
7. WROOM32 Socket
8. Lolin32 Socket
9. Reset Switch
10. EB2 Port A Connector
11. EB2 Port B Connector
12. EB2 Port C Connector



BL0058 – Flowcode Compatibility

When selecting a target device in Flowcode choose:

ESP32 -> Misc -> BL0058.

In the General Options tab select the correct COM port for the ESP32 device. If no COM port is available then check your ESP32 device is connected to the USB and that the USB driver is correctly installed.

Please note the ESP32 needs to be connected to the USB to allow it to be re-programmed.

The E-block needs to be connected to the USB to allow Ghost (ICD/ICT) features.

Choose a Target

Chip	# Pins	Max MHz	Flash
ESP			
Espressif			
Misc			
BL0058			
ESP32_DEVKITV1	30	240	8388t
ESP32_T-Camera	20	240	8388t

Configure

Write config on download Download config now

Show descriptive names

Project information

Project title:

Detailed description:

Other options

Clock speed (MHz): [defines delay-related timings]
240

Simulation speed:
Fast (no updates)


Use supplementary code
Supplementary Code...

Auto clear watchdog

Use ## in constant decisions

Programmer Port:
COM3 (USB-SERIAL CH340)

Upstream - BL0058 - ESP32 Programmer



Upstream - BL0058 - ESP32 Programmer

Ghost Specification

VCC Voltage: 3V3
 ICD Pins: Clock = IO2 / Data = IO0
 ICT Digital Channels: 24
 ICT Analogue Channels: 16
 ICT Port Pins Map:

	7	6	5	4	3	2	1	0
PORTA	13 (36)	12 (37)	5	4 (32)	26 (41)	2 (34)	33 (5)	32 (4)
PORTB	25 (40)	0 (33)	22	27 (39)	19	18	15 (35)	14 (38)
PORTC	39 (3)	36 (0)	35 (7)	34 (6)	17	16		23



Input Only

() Analogue Input

Analogue available only when not using WiFi/Bluetooth

Upstream - BL0061 - ST ARM Programmer


The STARM microcontroller programmer connects to your PC via USB to provide you with a powerful microcontroller programming and debugging platform. The board can be used with various programming languages including: Assembly, C and Flowcode. To program the ARM on the board a free tool called mLoader is available to download from the Matrix TSL website. The board comes complete with a powerful series 4 ARM microcontroller. The board presents all port pins collected together as E-blocks 2 sockets. The board takes power from an external power supply or from the micro USB port. Using the board with Flowcode allows the use of the advanced Ghost debugging features including in circuit debugging, real time pin monitoring and bus decoding. ST-LINK compatible sockets are fitted to provide alternative reprogramming and debugging techniques.




Upstream - BL0061 - ST ARM Programmer

Board Layout


1. DC Power Jack 7.5 - 12V
2. Micro USB Socket
3. Status LEDs
4. Power Output Terminals
5. Ghost Microcontroller IC
6. High Speed USB Transceiver
7. Target Microcontroller STM32F446
8. USB / A6&7 Selection Switch
9. Target Micro USB Socket
10. Reset Switch
11. EB2 Port A Connector
12. EB2 Port B Connector
13. EB2 Port C Connector
14. EB2 Port D Connector
15. EB2 Port E Connector
16. EB2 Port F Connector



BL0061 - Board Schematic



Upstream - BL0061 - ST ARM Programmer



Upstream - BL0061 - ST ARM Programmer

Ghost Specification


VCC Voltage: 3V3
 ICD Pins: Clock = D1 / Data = D0
 ICT Digital Channels: 48
 ICT Analogue Channels: 16
 ICT Port Pins Map:

	7	6	5	4	3	2	1	0
Port A	A7	A6	A5	A4	A3	A2	A1	A0
Port B	B7	B6	B5	B4	B3	B2	B1	B0
Port C	C7	C6	C5	C4	C3	C2	C1	C0
Port D	D7	D6	D5	D4	D3	D2	D1	D0
Port E	E7	E6	E5	E4	E3	E2	E1	E0
Port F	F7	F6	F5	F4	F3	F2	F1	F0


White = No Sampling / Red = Digital Only / Blue = Analogue Only / Green = Digital & Analogue

Upstream - BL0080 - 8-Bit PIC Multi-Programmer

The 8-bit PIC microcontroller programmer connects to your PC via USB to provide you with a powerful microcontroller programming and debugging platform. The board can be used with various programming languages including: Assembly, C and Flowcode. To program the PIC on the board a free tool called mLoader is available to download from the Matrix TSL website. The board will program a wide range of 18, 28 and 40 pin PICmicro microcontroller devices from the PIC16F and PIC18F series. The board presents all port pins collected together as E-blocks 2 sockets. The board takes power from an external power supply or from the micro USB port. Using the board with Flowcode allows the use of the advanced Ghost debugging features including in circuit debugging, real time pin monitoring and bus decoding. Microchip PICkit compatible sockets are fitted to provide an alternative reprogramming and debugging techniques. A powerful 40 pin PIC16F18877 device is shipped with the multiprogrammer.




BL0080 - Block Diagram




Upstream - BL0080 - 8-Bit PIC Multi-Programmer

Board Layout


1. DC Power Jack 7.5 - 12V
2. Micro USB Socket
3. Status LEDs
4. Power Output Terminals
5. Ghost Microcontroller IC
6. High Speed USB Transceiver
7. Target Microcontroller 16F18877
8. Voltage Selection Switch
9. Oscillator Selection Switch
10. 8MHz Socketed Crystal
11. Reset Switch
12. EB2 Port A Connector
13. EB2 Port B Connector
14. EB2 Port C Connector
15. EB2 Port D Connector
16. EB2 Port E Connector



BL0080 - Board Schematic



Upstream - BL0080 - 8-Bit PIC Multi-Programmer



Upstream - BL0080 - 8-Bit PIC Multi-Programmer

Ghost Specification

VCC Voltage: 5V / 3V3
 ICD Pins: Clock = B6 / Data = B7
 ICT Digital Channels: 35
 ICT Analogue Channels: 17
 ICT Port Pins Map:

	7	6	5	4	3	2	1	0
Port A	A7 **	A6 **	A5	A4	A3	A2	A1	A0
Port B	B7	B6	B5	B4	B3	B2	B1	B0
Port C	C7	C6	C5	C4	C3	C2	C1	C0
Port D	D7	D6	D5	D4	D3	D2	D1	D0
Port E					E3	E2	E1	E0

White = No Sampling / Red = Digital Only / Blue = Analogue Only / Green = Digital & Analogue


** Port pins A6 and A7 are only available when the microcontroller is configured for an internal oscillator and the XTAL / A6&7 switch on the board is in the A6&7 position.

Upstream - BL0086 - 8-Bit AVR Programmer

The AVR Programmer connects to your PC via USB to provide you with a powerful microcontroller programming and debugging platform. The board can be used with various programming languages including: Assembly, C, Arduino IDE and Flowcode. To program the AVR on the board a free tool called mLoader is available to download from the MatrixTSL website. The board comes complete with a powerful ATMEGA328P microcontroller. The board presents all port pins collected together as E-blocks 2 sockets. The board takes power from an external power supply or from the micro USB port. Using the board with Flowcode allows the use of the advanced Ghost debugging features including in circuit debugging, real time pin monitoring and bus decoding. Microchip AVR-ISP compatible sockets are fitted to provide an alternative reprogramming and debugging techniques.




BL0086- Block Diagram




Upstream - BL0086 - 8-Bit AVR Programmer

Board Layout

1. DC Power Jack 7.5 - 12V
2. Micro USB Socket
3. Status LEDs
4. Power Output Terminals
5. Ghost Microcontroller IC
6. High Speed USB Transceiver
7. Target Microcontroller ATMEGA328P
8. Voltage Selection Switch
9. 16MHz SMD Crystal
10. Reset Switch
11. EB2 Port C Connector
12. EB2 Port D Connector
13. EB2 Port B Connector



Upstream - BL0086 - 8-Bit AVR Programmer



Upstream - BL0086 - 8-Bit AVR Programmer

Ghost Specification


VCC Voltage: 5V / 3V3
 ICD Pins: Clock = B5 / Data = B4
 ICT Digital Channels: 20
 ICT Analogue Channels: 8
 ICT Port Pins Map:

	7	6	5	4	3	2	1	0
Port C	ADC7	ADC6	C5	C4	C3	C2	C1	C0
Port D	D7	D6	D5	D4	D3	D2	D1	D0
Port B			B5	B4	B3	B2	B1	B0


White = No Sampling / Red = Digital Only / Blue = Analogue Only / Green = Digital & Analogue

Upstream - BL0093 - FPGA Programmer

The FPGA E-block 2 board combines the speed and power of the Altera Cyclone IV series FPGA devices with the simplicity of E-blocks to provide six full 8-bit E-blocks compatible I/O ports. The FPGA is programmed using Intel's Quartus software via a USB blaster cable from Terasic. The FPGA device used is a EP4CE10E22 which has 10320 macrocells and 414Kb of RAM. The board also features a 4MB configuration device allowing the FPGA to auto start with the users last program on power up or reset. Full course notes are available.




BL0093- Block Diagram




Upstream - BL0093 - FPGA Programmer

Board Layout


1. DC Power Jack 7.5 - 12V
2. Status LEDs
3. Power Output Terminals
4. FPGA EP4CE10E22
5. Config Device
6. 24MHz Digital Clock
7. Reset Switch
8. EB2 Port A Connector
9. EB2 Port B Connector
10. EB2 Port C Connector
11. EB2 Port D Connector
12. EB2 Port E Connector
13. EB2 Port F Connector
14. JTAG Programming Header
15. Active Serial Programming Header



BL0093 - Board Schematic



Upstream - BL0093 - FPGA Programmer



Upstream - BL0093 - FPGA Programmer


FPGA Pin Specification

IO Voltage: 3V3
 Core Voltage: 1V2 / 2V5
 Clock Input: CLK1_23
 Digital Pins: 48

	7	6	5	4	3	2	1	0
Port A	B7_120	B7_119	B7_115	B7_114	B7_113	B7_112	B7_111	B7_110
Port B	B5_84	B5_83	B5_80	B5_77	B5_76	B5_75	B5_74	B5_73
Port C	B4_66	B4_65	B4_64	B4_60	B4_59	B4_58	B4_55	B4_54
Port D	B3_50	B3_49	B3_46	B3_44	B3_43	B3_42	B3_39	B3_38
Port E	B8_138	B8_137	B8_136	B8_135	B8_133	B8_132	B8_129	B8_128
Port F	B2_28	B6_106	B6_105	B6_104	B6_103	B6_100	B6_99	B6_98


Reprogramming using mLoader

To reprogram the E-blocks2 hardware outside of Flowcode you can use the mLoader software to transfer a pre-compiled .hex file onto the microcontroller device. mLoader is available to download from the Matrix TSL website www.matrixtsl.com.



Reprogramming using Flowcode

To setup Flowcode to program the E-blocks2 upstream hardware simply choose your selected board from the Misc family when picking a target microcontroller device. If using the BL0080 board and a none standard microcontroller (PIC16F18877) then simply choose the microcontroller from the list.




Ensure the USB drivers are correctly installed and then simply click the compile to chip button to send the Flowcode program to the microcontroller on the board.

Ghost - Auto Board ID using Flowcode


Auto board identification support for the E-blocks 2 range is available in Flowcode 7.3 onward.

To see the connected E-blocks2 boards in Flowcode 7.3 you need the Test & Debugging feature pack. Then simply click on the View -> Console menu item to bring up the console window. The Default tab shows the Auto ID board connections.



```
Consoles
Default
BLO080 Ghost2 PIC MultiProgrammer
PORTA: BLO114 Combo E-block
PORTB: BLO114 Combo E-block
PORTC: BLO167 LED Array E-block
PORTD: BLO152 Zigbee
PORTE: Unconnected
(read-only)
```

Photo showing the connected hardware



Ghost - In Circuit Debug (ICD) using Flowcode

In Circuit Debug (ICD) allows you to follow and control the execution of your Flowcode program on real world hardware using Flowcode to control the program execution. ICD support for the E-blocks 2 range is available in Flowcode 7.3 onwards.

To enable ICD first connect the E-blocks 2 board via USB and ensure the USB drivers are installed correctly. Once the board is detected the three Ghost icons will become available.




Click the ICD icon to toggle ICD mode on and off, When ICD mode is enabled the icons will turn green and the ICD LED will light on the E-blocks board.




Compile the program to the device as normal using the Compile To Chip button. Please note that a program in ICD mode will wait for the trigger from Flowcode before being allowed to run.

The simulation controls (Run, Pause, Stop, Step) will now control the execution of the hardware.



You can set or clear breakpoints while the program is stopped or paused by right clicking an icon and choosing Toggle Breakpoint. Active breakpoints will be shown with a red circle highlighting the Flowchart icon. When paused or stepping the current icon will be highlighted in green.

When the program is paused or running slowly variable values can be monitored or changed using the simulation debugger window. Variables can be added to the window by double clicking the "Expression" field and typing the name of the variable you want to display or control. The value of the variable can be altered by selecting the corresponding value text field and manually changing the value. Please note that only Global variables can be used with the simulation debugger.




Ghost - In Circuit Test (ICT) using Flowcode

In Circuit Test (ICT) allows you to monitor the analogue and digital signals surrounding your target microcontroller. ICT support for the E-blocks 2 range is available in Flowcode 7.3 onwards.


To enable ICT first connect the E-blocks 2 board via USB and ensure the USB drivers are installed correctly. Once the board is detected the three Ghost icons will become available.



The first time you click the ICT button the Ghost Options window will appear allowing you to control which pins are being monitored. The ICT Analog tab allows you to control which analogue pins will be monitored. The ICT Digital tab allows you to control which digital pins will be monitored.



Flowcode will attempt to make a best guess to enable the pins that are being used in the program. The Untick All and Tick Used buttons can be helpful when changing the program or adding and removing pins. The settings tab lets you control the ICT digital and analog sample speeds individually.





When ICT is active a red box will appear around the ICT button on the toolbar and the ICT LED will light on the E-blocks board.


Ghost - In Circuit Test (ICT) using Flowcode

ICT data can be seen on the Data Recorder and Oscilloscope windows.

The Oscilloscope is useful for recurring signals where you can set a repeating trigger and inspect a part of a waveform in isolation. The Oscilloscope window allows you to assign various data sources to one of the four available waveforms and acts a lot like a standard electronics oscilloscope.



The Data Recorder is useful for comparing multiple signals over time. To add signals to the data recorder window simply use the Scope Monitor component from the Tools section of the Component Toolbar. Each Scope Monitor component provides up to 4 digital pins and 2 analogue pins via the component properties. If more pins are required then simply add another Scope Monitor component to the Flowcode panel. 



ICT can be used in isolation or in conjunction with ICD to combine external pin voltages with internal program flow control.

LCD - Embedded Font Set

Here is the inbuilt alphanumeric font set. As with standard alphanumeric displays, locations 0-7 are user programmable allowing you to create your own characters or glyphs. The columns shown in green are common with standard HD44780 displays, other columns are specific to the BL0169 and the BL0114 displays only.

b7- b3 -b0	b4	0000	0001	0010	0011	0100	0101	0110	0111	1000	1001	1010	1011	1100	1101	1110	1111
0000	CG RAM (1)			0	a	P	`	P	E	\		-	タ	ミ	α	ρ	
0001	(2)			!	1	A	Q	a	q	e	θ	μ	ア	チ	△	Δ	Q
0010	(3)			"	2	B	R	b	r	e	ψ	「	イ	ツ	×	β	θ
0011	(4)			#	3	C	S	c	s	e	τ	」	ウ	テ	ε	ε	∞
0100	(5)			\$	4	D	T	d	t	0	∕	\	エ	ト	⊥	μ	Ω
0101	(6)			%	5	E	U	e	u	0	∕	.	オ	ナ	∩	α	Ω
0110	(7)			&	6	F	V	f	v	0	∕	ラ	カ	ニ	ヨ	ρ	Σ
0111	CG RAM (8)			°	7	G	W	g	w	△	∕	フ	キ	ヌ	ラ	Q	π
1000				<	8	H	X	h	x	ψ	∕	イ	ク	ネ	リ	∫	×
1001				>	9	I	Y	i	y	°	∕	ウ	ケ	ル	∩	∩	∩
1010				*	:	J	Z	j	z	0	∕	エ	コ	∩	レ	i	≠
1011				+	:	K	I	k	i	0	∕	オ	サ	ヒ	ロ	×	π
1100				•	<	L	¥	l	l	∩	∕	カ	シ	フ	ワ	φ	π
1101				-	=	M	J	m	j	i	∕	ユ	ズ	∩	∩	±	÷
1110				•	>	N	^	n	→	△	0	ヨ	セ	ホ	°	π	
1111				/	?	0	_	o	←	∩	∩	ツ	リ	マ	°	o	■

LCD Key differences

There are a number of key differences between this LCD and the standard HD44780 type displays which are listed below.

- Scrolling and blinking cursor display commands are not supported.
- Printing characters to the display automatically moves through lines 0,1,2,3 rather than the usual 0,2,1,3.
- Enhanced character set support.



Matrix Technology Solutions
The Factory,
33 Gibbet Street,
Halifax, HX1 5BA,
United Kingdom

t: +44 (0) 1422 252380
f: +44 (0) 1422 341830
e: sales@matrixtsl.com

www.matrixtsl.com

